

Function	Keystroke
Place Wire	P, W
Place Net Label	P, N
Break Wire	E, W
While routing, toggles through routing angles	(Shift) (Spacebar)
Toggles Grid spacing	G
Opens Grid Dialog	(Shift) G
View Full Document	V, D

Function	Keystroke
Place Track	P, T
Place Via	P, V
Change layer	* (on Number Pad)
Change available routing layer	* (on Keypad)
Open Design Rules / Run Design Rules	D, R / T, D, R
“Show / Hide / Re-Pour” Copper Pours	T, G, E / T, G, H / T, G, A
Re-pour selected Layer	T, G, R
While routing, toggles through routing angles	(Shift) (Spacebar)
Toggle through grid snap modes	(Shift) E
Flip Board	V, B
View Full PCB (useful in 3d mode when you’ve zoomed out too much and lost the PCB!	V, F